

Instructions

Einbauanleitung

Instrucciones de instalación


Instructions d'installation

게이밍 데스크


조립설명서

ゲーミングデスク

組立説明書




①x4




M8x40

②x12



M6x16

③x2



M6x20

④x6




M4x16

⑤x2



M4x30


⑥x4




⑦x1




⑧x1




Ax1




Bx1




Cx1




Dx2




Ex1




Fx1




Gx1




Hx1



Ix1




Jx2



Kx2


















Lx3



Mx1





FINISH